

WARRANTY INFO

La Crosse Technology, Ltd. provides a 1-year limited time warranty (from date of purchase) on this product relating to manufacturing defects in materials & workmanship.

La Crosse Technology, Ltd

2830 S. 26th St.

La Crosse, WI 54601

For Full Warranty Details, Visit: www.lacrossetechnology.com/support

CARE + MAINTENANCE

- Do not mix old and new batteries.
- Do not mix Alkaline, Lithium, standard, or rechargeable batteries.
- Always purchase the correct size and grade of battery most suitable for intended use.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries have with correct polarity (+ / -).
- Remove batteries from equipment that will not to be used for an extended period.
- Promptly remove expired batteries.

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Increase separation between equipment & receiver.
- Consult the dealer or an experienced radio/TV technician for help.

This device must not be co-located or operating in conjunction with any other antenna or transmitter.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

CAUTION!

The manufacturer is not responsible for any radio or TV interference caused by unauthorized changes or modifications to this equipment. Such changes or modifications could void the user authority to operate the equipment.

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher. This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences. All trademarks and patents are recognized.

WARNING: This product can expose you to chemicals including styrene, which is known to the State of California to cause cancer. For more information go to: www.P65Warnings.ca.gov



LA CROSSE®
TECHNOLOGY

RAIN SENSOR




Model: TX145R

DC: 100319

POWER UP

Remove the Rain Sensor funnel and insert 2 “AA” batteries into the Battery Compartment.



MOUNTING


- Mount the Rain Sensor horizontally and ensure it's level.
- The sensor should be mounted more than 3 feet above ground.
- Your Rain sensor needs to be in an open area for accurate readings.
- Make sure the base of your Rain Sensor is not in a depression.
- This Rain Sensor has drainage holes in the bottom to allow it to self-empty.
- View sensor mounting video at: bit.ly/Rain_SensorMounting

RAIN READING ON WEATHER STATION

Please see your specific Weather Station manual for instructions to read the Rain Sensor in the station itself.

JOIN THE CONVERSATION

Ask questions, watch detailed setup videos, and provide feedback on our social media outlets!



SPECIFICATIONS

- Rainfall Range: 0-393.6 in (0-9999mm)
- Transmission Range: 330 Feet (100 Meters)
433MHz open air
- Power Requirements: 2 “AA” batteries (included)
- Update Interval: Every 45 Seconds
- Sensor Dimensions: 7.16” L x 5.24” W x 5.04” H
(18.2 cm L x 13.3 cm W x 12.8 cm H)